
QUICK START GUIDE

Stanlee 32″ Frameless LED FHD Smart TV

32″ LED · Full HD · Android TV




Register warranty
Scan, upload invoice

Help on WhatsApp
+91 89293 94607

1 Unbox


What's in the box?




Stanlee QLED TV




Stanlee Smart Remote



TV Stands and Screws



x2 AA Batteries



Power Cable



Quick Start Guide

2 Set up in 4 steps

Fix the stand

Screw both feet on, TV face-down on a soft cloth. Or let our team wall-mount it.

Plug in & switch on

Batteries in the remote, then press Power.

Connect Wi-Fi

Pick your language, then your Wi-Fi network.

Sign in

Sign in with Google to use the Play Store.

3 Your remote



Power
Turn the TV on or off

HOME
Home screen

SOURCE
Switch to set-top box, HDMI, USB

OK / ENTER + arrows
Move and select

MENU · EXIT
Settings menu · close

VOL / CH
Volume and channels

P.MODE · S.MODE
Picture mode · sound mode

SLEEP
Auto switch-off timer

Netflix · YouTube · Prime Video · JioHotstar
Open the app in one press

Set-top box / console / soundbar: plug in with HDMI, then choose that HDMI from Input / Source. This TV has 2 × HDMI · 2 × USB.

4 Specs

SCREEN SIZE **32″ LED**	RESOLUTION **Full HD**
HDR **Not supported**	AUDIO **20W stereo speakers**
PLATFORM **Android TV**	MEMORY **1 GB RAM + 8 GB storage**
PORTS **2 × HDMI · 2 × USB**	CONNECTIVITY **Wi-Fi + Bluetooth**
MODEL **STANLEE 3286 FLSM 612**	

5 Quick fixes

No power	Check the plug and switch, try another socket.
No picture from set-top box	Press Input / Source and pick the right HDMI.
Remote not working	Change batteries. Re-pair it from Settings.
Apps slow	Restart the router and the TV, install updates.

Still stuck? We fix most things on a video call.

Call / WhatsApp +91 89293 94607 · support@stanleeindia.com
Mon–Sat, 10 am – 7 pm · keep your invoice and serial number ready

Safety: lift with two people · keep 10 cm around the vents · keep away from water · unplug in storms · do not open the back cover.