QUICK START GUIDE

Stanlee 58″ Google TV — Mini LED

58″ Mini LED · Ultra HD 4K · Google TV




Register warranty
Scan, upload invoice

Help on WhatsApp
+91 89293 94607

1 Unbox


What's in the box?




Stanlee QLED TV




Stanlee Smart Remote



TV Stands and Screws



x2 AA Batteries



Power Cable



Quick Start Guide

2 Set up in 4 steps

Fix the stand

Screw both feet on, TV face-down on a soft cloth. Or let our team wall-mount it.

Plug in & switch on

Batteries in the remote, then press Power.

Connect Wi-Fi

Pick your language, then your Wi-Fi network.

Sign in

Sign in with Google (or use the Google Home app on your phone).

3 Your remote



Power
Turn the TV on or off

Mic
Talk to Google Assistant

Home
Google TV home screen

Back
Go back one step

OK + arrows
Move and select

Input
Switch to set-top box, HDMI, USB

Settings
Picture, sound, Wi-Fi

VOL / CH
Volume and channels

Netflix · YouTube · Prime Video
Open the app in one press

Set-top box / console / soundbar: plug in with HDMI, then choose that HDMI from Input / Source. This TV has 3 × HDMI · 2 × USB · 1 × AUX · LAN.

4 Specs

SCREEN SIZE **58″ Mini LED**	RESOLUTION **Ultra HD 4K**
HDR **Supported**	AUDIO **30W + 30W speakers**
PLATFORM **Google TV**	PORTS **3 × HDMI · 2 × USB · 1 × AUX · LAN**
CONNECTIVITY **Wi-Fi + Bluetooth + LAN**	MODEL **STANLEE-6088 MINI LED 4K GC**

5 Quick fixes

No power	Check the plug and switch, try another socket.
No picture from set-top box	Press Input / Source and pick the right HDMI.
Remote not working	Change batteries. Re-pair it from Settings.
Apps slow	Restart the router and the TV, install updates.

Still stuck? We fix most things on a video call.

Call / WhatsApp +91 89293 94607 · support@stanleeindia.com
Mon–Sat, 10 am – 7 pm · keep your invoice and serial number ready

Safety: lift with two people · keep 10 cm around the vents · keep away from water · unplug in storms · do not open the back cover.